

06.06.2025

# Standardisation of isonames for airbags

VDA AK27 working group „Airbagsimulation“



1. Reason for standardisation
2. Proposal of the VDA working group “Airbagsimulation”
3. Necessary additions to the ISO/TS 13499 – RED B
4. Addition figures for the ISO/TS 13499 – RED C

# Reason for Standardisation

## Background and Advantages

### 1. Background

- Currently, the specifications of ISO/TS 13499 leave some room for interpretation when choosing channel names for airbags.
- As a result, the channel names are different for OEMs and manufacturers.

### 2. Target and Advantage

- The VDA working group “Airbag Simulation” has developed a proposal for the standardization of channel names in order to reduce the additional work involved in converting channel names.
- These were extended to include iso names for simulation variables.

ISO TC 22/SC 12

Date: 2012-05-04

ISO/TS 13499 - RED B : 2012 E

ISO/TC 22/SC 12/WG 3

Secretariat: AFNOR

Road vehicles - Multimedia data exchange format for impact tests

*Véhicules routiers — Format d'échange de données multimédia pour les essais de choc*

Related electronic document B

Channel Codes

— Version 1.6 —

Document type: Related electronic document  
Document language: E

ISO MME Database 2.41 - Data Release 1.6

1. Reason for standardisation
2. Proposal after consultation in MME Task Force
3. Necessary additions to the ISO/TS 13499 – RED B
4. Addition figures for the ISO/TS 13499 – RED C

# Proposal of the VDA working group "Airbagsimulation" **VDA**

## Example for Frontairbag left

Code	Description	Remarks
11 AIRB ?? ?? AF ?? ? ?	Airbag	Frontairbag (left hand drive, right hand passenger)
11 AIRB 00 00 AF PR ? ?	Airbag	Frontairbag left pressure
11 AIRB 01 00 AF PR ? ?	Airbag	Frontairbag left pressure (2. measurement)
11 AIRB 02 00 AF PR ? ?	Airbag	Frontairbag left pressure (3. measurement)
11 AIRB 00 00 AF TI ? ?	Airbag	Frontairbag left ignition time
11 AIRB S1 00 AF CU ? ?	Airbag	Frontairbag left ignition current 1st stage (sensor)
11 AIRB S2 00 AF CU ? ?	Airbag	Frontairbag left ignition current 2nd stage (sensor)
11 AIRB A1 00 AF CU ? ?	Airbag	Frontairbag left ignition current 1st adaptive (sensor)
11 AIRB A2 00 AF CU ? ?	Airbag	Frontairbag left ignition current 2nd adaptive (senso
11 AIRB S1 SQ AF CU ? ?	Airbag	Frontairbag left ignition current 1st stage (timer)
11 AIRB S2 SQ AF CU ? ?	Airbag	Frontairbag left ignition current 2nd stage (timer)
11 AIRB A1 SQ AF CU ? ?	Airbag	Frontairbag left ignition current 1st adaptive (timer)
11 AIRB A2 SQ AF CU ? ?	Airbag	Frontairbag left ignition current 2nd adaptive (timer)
11 AIRB S1 00 AF VO ? ?	Airbag	Frontairbag left ignition voltage 1st stage (sensor)
11 AIRB S2 00 AF VO ? ?	Airbag	Frontairbag left ignition voltage 2nd stage (sensor)
11 AIRB A1 00 AF VO ? ?	Airbag	Frontairbag left ignition voltage 1st adaptive (sensor)
11 AIRB A2 00 AF VO ? ?	Airbag	Frontairbag left ignition voltage 2nd adaptive (senso
11 AIRB S1 SQ AF VO ? ?	Airbag	Frontairbag left ignition voltage 1st stage (timer)
11 AIRB S2 SQ AF VO ? ?	Airbag	Frontairbag left ignition voltage 2nd stage (timer)
11 AIRB A1 SQ AF VO ? ?	Airbag	Frontairbag left ignition voltage 1st adaptive (timer)
11 AIRB A2 SQ AF VO ? ?	Airbag	Frontairbag left ignition voltage 2nd adaptive (timer)
11 AIRB ?? ?? AF FO * ?	Airbag	Frontairbag left force (* = X, Y, Z, R)
11 AIRB ?? ?? AF AC * ?	Airbag	Frontairbag left acceleration (* = X, Y, Z, R)
11 AIRB ?? ?? AF VE * ?	Airbag	Frontairbag left velocity (* = X, Y, Z, R)
11 AIRB ?? ?? AF DS * ?	Airbag	Frontairbag left displacement (* = X, Y, Z, R)
11 AIRB 00 00 AF MF I ?	Airbag	Frontairbag left massflow in
11 AIRB 00 00 AF MF O ?	Airbag	Frontairbag left massflow out (sum of all leakage)
11 AIRB ?? ?? AF MF O ?	Airbag	Frontairbag left massflow out (single leakage)
11 AIRB 00 TO AF MF 0 ?	Airbag	Frontairbag left massflow in - sum massflow out
11 AIRB 00 TO AF MA 0 ?	Airbag	Frontairbag left total mass
11 AIRB 00 00 AF VU 0 ?	Airbag	Frontairbag left volume
11 AIRB 00 00 AF AR 0 ?	Airbag	Frontairbag left surface area
11 AIRB 00 00 AF TE 0 ?	Airbag	Frontairbag left temperature

New Fine location 1  
Sx = for numbering stages  
Ax = for numbering adaptivities

New Direction  
I = In  
O = Out

New Dimension  
MF = massflow  
AR = surface area

Total is a value of Fine location 2

New Fine location 1  
VE = vent  
FB = fabric  
SE = seam  
MO = module  
...

Use Fine location 2  
For numbering of  
e.g. vents

1. Reason for standardisation
2. Proposal of the VDA working group “Airbagsimulation”
3. Necessary additions to the ISO/TS 13499 – RED B
4. Addition figures for the ISO/TS 13499 – RED C

# Necessary additions to the ISO/TS 13499 – RED B

## Missing points

To implement the standard, the following points are missing in ISO/TS 13499 — RED B :

- **Dimension**

- MF for massflow
- AR for surface area

- **Direction**

- I for in (e.g. massflow in)
- O for out (e.g. massflow out)
- ~~T for total (e.g. total mass)~~ → use Fine Location 2

- **Fine Location 1**

- VE for vent
- FB for fabric
- SE for seam
- MO for module
- S1, S2, S3, ... for numbering stages of an airbag
- A1, A2, A3, ... for numbering adaptivities of an airbag

- **Fine Location 3**



- AV for Airbag Vehicle

1. Reason for standardisation
2. Proposal of the VDA working group “Airbagsimulation”
3. Necessary additions to the ISO/TS 13499 – RED B
4. Addition figures for the ISO/TS 13499 – RED C

# Airbags for front protection (1)

## Frontal Airbags



- ? ? AIRB ???? AF Drive and Passenger Airbag
- ? 1 KNBO ???? AF Knee Airbag 1. seat row position 1
- ? 3 KNBO ???? AF Knee Airbag 1. seat row position 3
- ? 4 KNBO ???? AF Knee Airbag 2. seat row position 4
- ? 6 KNBO ???? AF Knee Airbag 2. seat row position 6
- ? ? FOWE ???? AF Footwell Airbag



# Airbags for front protection (2)

## Front Airbags in seat



- ? ? SEBE ???? AF Seat Belt Airbag
- ? ? SEPN ???? AF Seat Ramp Airbag



# Airbags for side protection (1)

## Side Airbags



- ? ? SEBA ???? AS Side Airbag seat mounted
- ? ? SEPN ???? AS Side Airbag seat pan mounted
- ? ? DOOR ???? AS Side Airbag door mounted



# Airbags for side protection (2)

## Interaction Airbags




- ? 1 SEBA ???? AI Interaction/Farside/Center Airbag seat position 1 mounted
- ? 3 SEBA ???? AI Interaction/Farside/Center Airbag seat position 3 mounted
- ? 4 SEBA ???? AI Interaction/Farside/Center Airbag seat position 4 mounted
- ? 6 SEBA ???? AI Interaction/Farside/Center Airbag seat position 6 mounted
- ? 2 ROOF ???? AI Interaction Airbag roof mounted 1. seat row seat position 1 and 3
- ? 5 ROOF ???? AI Interaction Airbag roof mounted 2. seat row seat position 4 and 6



# Airbags for side protection (3)

## Head Airbags

- ? 1 ROFR ???? AH Roof Frame Head Airbag (only on position 1)
- ? 3 ROFR ???? AH Roof Frame Head Airbag (only on position 3)
- ? 4 ROFR ???? AH Roof Frame Head Airbag
- ? 6 ROFR ???? AH Roof Frame Head Airbag
- ? ? DOOR ???? AH Door Head Airbag



# Airbags for other protection

## Pedestrian Airbag


- ? 2 HOOD ???? AP Hood Airbag
- ? 2 WIND ???? AP Window Airbag

## Rear Airbag

- ? ? HERE ???? AR Head Restraint Airbag

## Car Airbag

- ? 2 BUMP ???? AV Bumper Airbag Front
- ? 4 BUMP ???? AV Bumper Airbag Left Side
- ? 6 BUMP ???? AV Bumper Airbag Right Side





# Appendix

Standards for all airbag types

# Your contact person

For questions and background information



**Susanne Weber**

BMW Group

susanne.sw.weber@bmw.de