



Head - AC  
HEAD 00 00 TH AC X, -Y, -Z

Head - AV  
HEAD 00 00 TH AV X, -Y, -Z

Neck Cable - FO  
NECK FR 00 TH FO Z  
NECK RE 00 TH FO Z

Neck Upper - FO/MO  
NECK UP 00 TH FO X, -Y, -Z  
NECK UP 00 TH MO X, -Y, -Z

Head/Neck - AN  
NECK UP 00 TH AN Y

Clavicle - FO  
CLAV RI IN TH FO X, -Z  
CLAV RI OU TH FO X, -Z

Upper Arm Right - FO/MO  
UPAR RI 00 TH FO X, -Y, -Z  
UPAR RI 00 TH MO X, -Y, -Z

Thoracic Spine T1 - AC  
THSP 01 00 TH AC X, -Y, -Z

Chest Upper - DS  
CHST RI UP TH DC 0  
CHST RI UP TH VO 0  
CHST RI UP TH AN Y, -Z  
CHST LE UP TH DC 0  
CHST LE UP TH VO 0  
CHST LE UP TH AN Y, -Z

Chest Lower - DS  
CHST RI LO TH DC 0  
CHST RI LO TH VO 0  
CHST RI LO TH AN Y, -Z  
CHST LE LO TH DC 0  
CHST LE LO TH VO 0  
CHST LE LO TH AN Y, -Z

Abdomen - DS  
ABDO RI 00 TH DC 0  
ABDO RI 00 TH VO 0  
ABDO RI 00 TH AN Y, -Z  
ABDO LE 00 TH DC 0  
ABDO LE 00 TH VO 0  
ABDO LE 00 TH AN Y, -Z

Head - AC  
HEAD TP 00 TH AC X, -Y  
HEAD RE 00 TH AC X, -Y  
HEAD LE 00 TH AC X, -Y

Face - FO  
HEAD UP LE TH FO X  
HEAD UP RI TH FO X  
HEAD MI LE TH FO X  
HEAD MI RI TH FO X  
HEAD LO 00 TH FO X

Neck Lower - FO/MO  
NECK LO 00 TH FO X, -Y, -Z  
NECK LO 00 TH MO X, -Y, -Z

Clavicle - FO  
CLAV LE IN TH FO X, -Z  
CLAV LE OU TH FO X, -Z

Upper Arm Left - FO/MO  
UPAR LE 00 TH FO X, -Y, -Z  
UPAR LE 00 TH MO X, -Y, -Z

Thoracic Spine T4 - AV  
THSP 04 00 TH AV X, -Y, -Z

Thoracic Spine T4 - AC  
THSP 04 00 TH AC X, -Y, -Z

Sternum - AC  
STRN 00 00 TH AC X

Thoracic Spine T12 - AC  
THSP 12 00 TH AC X, -Y, -Z

Thoracic Spine T12 - FO/MO  
THSP 12 00 TH FO X, -Y, -Z  
THSP 12 00 TH MO X, -Y

Abdomen - AC  
ABDO 00 00 TH AC X

#### Note

The IR-TRACC devices fitted to this dummy record a voltage. It is more normal to exchange the distance channel, IR-TRACC total length, eg CHST RI UP TH DC 0. If it is only possible to supply a change in length, the displacement code should be used, eg CHST RI UP TH DS 0



